

# Integrated Mount Tester

## User Manual

(V2.1)

---



- Thank you for purchasing the Integrated Mount Tester. Please read the manual before using the Integrated Mount Tester and use properly.
- For using the Integrated Mount Tester safely, please first read the「Safety information」carefully in the manual.
- The manual should be kept well in case of reference.
- Keep the S/N label for after-sale service within warranty period. Product without S/N label will be charged for repair service.
- If there is any question or problem while using the Integrated Mount Tester, or damages occurred on the product, please contact our technical department.

# Content

1 .Safety information-----	1
2. Integrated Mount Tester Introduction-----	3
2.1 General -----	3
2.2 Features-----	3
2.3 Packing list-----	6
2.4 Function interface -----	7
3. Operation -----	11
3.1 Installing the Battery-----	11
3.2 Instrument connection -----	12
3.2.1 IP camera connection -----	12
3.2.2 Analog camera connection -----	13
3.2.3 HD Coaxial camera connection-----	14
3.2.4 HDMI IN -----	14
3.3 OSD menu -----	15
3.3.1 Drop-down Menu -----	15
3.3.2 Short cut-menu -----	16
3.3.3 Screen capture -----	17
3.3.4 Link monitor-----	17
3.3.5 TesterPlay-----	18
3.3.6 IP discovery -----	19
3.3.7 ONVIF test-----	20
3.3.8 Test tool -----	34
3.3.9 IP camera test-----	39
3.3.10 Virtual IPC -----	42
3.3.11 HDMI IN -----	43
3.3.12 Video monitor test（CVBS）-----	47
3.3.13 SDI/EX-SDI Camera Test-----	55
3.3.14 CVI camera test -----	57
3.3.15 TVI camera test-----	63

3.3.16	AHD camera test -----	65
3.3.17	AUTO HD -----	67
3.3.18	Cable Test -----	68
3.3.19	RJ45 cable TDR test -----	71
3.3.20	Cable Tracer-----	73
3.3.21	TDR3.0 cable test （*optional） -----	74
3.3.22	Analog video generator-----	78
3.3.23	Network tool -----	80
(1)	IP address scan-----	80
(2)	PING Test-----	80
(3)	Network test (Ethernet bandwidth test) -----	81
(4)	Port Flashing-----	85
(5)	DHCP server-----	86
(6)	Trace route -----	86
(7)	Link monitor-----	87
3.3.24	Rapid IP Discovery -----	88
3.3.25	PoE power / DC12V 2A and DC 5V 2A USB power output -----	88
3.3.26	12V power input test -----	90
3.3.27	Digital Multi-meter -----	91
3.3.28	Optical power meter -----	100
3.3.29	Visual Fault Locator -----	101
3.3.30	Audio Record -----	103
3.3.31	Data monitor -----	103
3.3.32	Audio player -----	104
3.3.33	Media Player -----	104
3.3.34	Update -----	105
3.3.35	LED Flashlight -----	106
3.3.36	Browser-----	107
3.3.37	DroNotes -----	107
3.3.38	System Setting -----	107
3.3.39	File explorer-----	110

3.4 Audio test-----	112
3.5 HDMI output -----	112
3.6 PoE power output -----	112
3.7 DC12V 2A power output-----	113
3.8 USB 5V 2A power output-----	114

# 1 .Safety information

- ◆ The tester is intended to use in compliance with the local rules of the electrical usage and avoid to apply at the places which are inapplicable for the use of electrics such as hospital, gas station,etc.
- ◆ To prevent the functional decline or failure, the product should not be sprinkled or damped.
- ◆ The exposed part of the tester should not be touched by the dust and liquid.
- ◆ During transportation and use, it is highly recommended to avoid the violent collision and vibration of the tester, lest damaging components and causing failure.
- ◆ Don't leave the tester alone while charging and recharging. If the battery is found severely hot, the tester should be powered off from the electric source at once. The tester should not be charged over 8 hours.
- ◆ Don't use the tester where the humidity is high. Once the tester is damp, power off immediately and move away other connected cables.
- ◆ The tester should not be used in the environment with the flammable gas.
- ◆ Do not disassemble the instrument since no component inside can be repaired by the user. If the disassembly is necessary indeed, please contact with the technician of our company.
- ◆ The instrument should not be used under the environment with strong electromagnetic interference.
- ◆ Don't touch the tester with wet hands or waterish things.
- ◆ Don't use the detergent to clean and the dry cloth is suggested to use. If the dirt is not easy to remove, the soft cloth with water or neutral detergent can be used. But the cloth should be tweaked sufficiently.

## About Digital Multi-meter

- ◆ Before using, you must select the right input jack, function and range.
- ◆ Never exceed the protection limit values indicated in specifications for each range of measurement.
- ◆ When the tester is linked to a measurement circuit, do not touch unused terminals.
- ◆ Do not measure voltage if the voltage on the terminals exceeds 660V above earth ground.
- ◆ At the manual range, when the value scale to be measured is unknown beforehand, set the range selector at the highest position.
- ◆ Always be careful when working with voltages above DC 60V or AC 40V, keep fingers behind the probe barriers while measuring.
- ◆ Never connect the meter with any voltage source while the function switch is in the current, resistance, capacitance, diode, continuity, otherwise it will damage the meter.

◆Never perform capacitance measurements unless the capacitor to be measured has been discharged fully.

◆Never measure any of resistance, capacitance, diode or continuity measurements on live circuits.

**Visual laser sources**

When you turn on visual laser sources, please don't stare at it, or will damage to eyes.

When not using it, please turn it off and cover the protective cap .

## 2. Integrated Mount Tester Introduction

### 2.1 General

The 7 inch touch screen Integrated Mount Tester is designed for maintenance and installation of IP cameras, analog cameras, CVI, TVI AHD, SDI cameras, as well as testing 4K H.265 camera by mainstream. The 1920x1200 resolution enables it to display network HD cameras and analog cameras in high resolution. The unit supports many ONVIF PTZ and analog PTZ control. The combination of touch screen and key buttons make the Integrated Mount Tester very user-friendly.

The tester is also a great tool for Ethernet network testing. It can test PoE power voltage, PING, and IP address searching. You can use the blue cable tracer to locate individual connected cables from a bundle of cables. Test LAN cable for proper connection termination. Other functions include providing 24W PoE power to your camera, HDMI IN and out, CVBS loop test, testing IP and analog at the same time, LED Flashlight, DC 12V 2A power output and much more. Its portability, user-friendly design and many other functions make the tester an essential tool for all installers or technicians.

### 2.2 Features

- ✧ New 7 inch touch screen CCTV tester with retina display, 1920\*1200 resolution.
- ✧ H.265, 4K video display via mainstream.
- ✧ In HDMI IN mode, it can convert *test* from analog to digital with dual test window IP & HDMI IN or Analog & HDMI IN.
- ✧ RJ45 cable TDR test and cable quality test, to test cable pair status, length, attenuation, reflectivity, impedance, skew and other parameters.
- ✧ Screen capture, long press the key “enter”, can capture screen interface and save it in any time.
- ✧ 12V power input test.
- ✧ “TesterPlay” app, support Tester, PC and mobile phone display at the same time. The android version mobile phone install “TesterPlay” app, or install VLC player in the PC, can real-time receiving screen information from the tester.
- ✧ Screen management, change function’s icons order, create new directory.
- ✧ Built in Wi-Fi, display image from the wireless camera, create WIFI Hotspot.
- ✧ Rapid video, auto scan the IP camera address, via one key to view the image.
- ✧ Screen lock, password lock and pattern lock are optional.
- ✧ Rapid IP scan, auto scan whole network or other network device’s IP address.



- ✧ Analog video generator, support CVBS loop test, tester can sends and receives color bar signal, check the continuity of the BNC cable.
- ✧ LAN interface traffic monitoring, display upload/download rate etc parameters when connecting LAN port or wireless WIFI.
- ✧ Shortcut button, drop-down menu,PoE power switch,IP setting,WLAN switch,HDMI IN functions etc. screen lock, password lock screen or pattern lock.
- ✧ IP discovery, do not need to know the first two digits of camera's IP address, it can auto-scan the whole network segment IP, and auto-modify tester's IP address.
- ✧ Rapid ONVIF, search camera quickly, auto log in and display image from the camera, activate camera.
- ✧ Test tool app is design for camera test, and modify IP, user name and password parameters,etc.
- ✧ ONVIF camera test, support 2592x1520.  
It is used unique hardware decoding, display image from the 4 MP camera via mainstream.  
You can select sub-stream to test higher resolution (such as 5MP...) camera.
- ✧ ONVIF IP camera video testing.
- ✧ Compatible with H.265/H.264/MPEG4/MJPEG IP cameras, and ACTI Customized service is available.
- ✧ Built in Wi-Fi, can receive image from wireless camera, as well as ONVIF and customized IP cameras.
- ✧ SDI/EX-SDI Digital camera image display, record and screen snapshot.
- ✧ HDCVI camera image display, 4X zoom, video record and playback,coaxial PTZ control and call camera OSD menu.
- ✧ TVI camera image display, 4X zoom, video record and playback,coaxial PTZ control and call camera OSD menu.
- ✧ AHD camera image display, 4X zoom, video record and playback,coaxial PTZ control and call camera OSD menu.
- ✧ HDMI signal output, supports up to 1080P.
- ✧ Analog camera image display, auto adapt and display the video format of NTSC/PAL.
- ✧ Support more than 30 protocols, such as PELCO-P,PELCO-D,SAMSUNG,etc.


- ✧ Video image digital zoom to view the image in greater detail.
- ✧ Snapshot function allows you to save the current image as a JPG file in the tester.
- ✧ Built in enhanced Analog video generator, send the color, pure blue and black image, test monitor transmission channel and debug display device, observe whether there are light spots or black spots on the monitor.
- ✧ LED Flashlight.
- ✧ LCD screen brightness/contrast/color saturation adjustable.
- ✧ Visual fault locator, to test fiber's bending and breakage.
- ✧ Optical power meter, test fiber loss and value.
- ✧ Digital Multimeter,DC and AC voltage measurement,resistance measurement,continuity test, diode measurements,capacitance measurement.
- ✧ PEAK video signal level, SYNC signal level, Color Burst chroma level measurement,test video signal attenuation.
- ✧ Cable tracer, by sending the audio signal, enables the blue cable tracer tester to find the connected cable from mess cables.
- ✧ Ping test, PING is the most conventional network debugging tools, it is used for testing if the connected IP camera or other network equipment's Ethernet port is working normally and the IP address is correct.
- ✧ In digital IP surveillance applications, if the IP camera's IP address is not known, the device cannot be used. An IP address scan can quickly search for the connected IP camera or other network device's IP address.
- ✧ The PoE voltage test can test for PoE voltage when a POE switch is supplying POE power to an IP camera.
- ✧ TDR cable test, test cable open circuit and short-circuit.
- ✧ Cable test, test LAN cable or telephone cable, UTP cable,etc. cable type and the sequence of wires will be displayed.
- ✧ Support RS485, rate 600~115200bps adjustable.
- ✧ PTZ protocol analysis, control protocol command displays to check RS485 transmission whether is normal, easy to find the fault device.
- ✧ PTZ control.Pan/tilts the P/T unit,zooms in/out the lens,adjusts the focus, aperture sets and the preset position.













- ✧ DC5V 2A power output for USB charging (No USB data exchange, voltage only),as a power bank for the phone.
- ✧ PoE power output, supply temporary power for PoE camera.
- ✧ Audio input and output, test and output the audio signal.
- ✧ 7.4V 37Wh Battery.
- ✧ Remaining battery charge indicator,Lithium Ion Polymer Battery can last 10 hours for normal use after charging for 5-6 hours.




## 2.3 Packing list

- 1). Tester
  - 2). Adaptor DC12V 2A
  - 3). Network cable tester
  - 4). Polymer lithium ion battery (7.4V DC 5000mAh)
  - 5). BNC cable
  - 6). RS485 cable
  - 7). SC,ST connector
  - 8). Multi-meter test leads one pair of red and black
  - 9). Output Power cable
  - 10). Audio cable
  - 11). TDR alligator clamp
  - 12). Safety cord
  - 13). Tool bag
  - 14). Manual
- (NOTICE:SD card is not default accessory, please purchase separately if necessary.)


## 2.4 Function interface




1		Press more than 2 seconds, turn on or off the device ,short press to turn on or off the men u display
2		Menu key
3		4xzoom the image displays
4		Far focus: Focus the image faraway
5		Near focus: Focus the image nearby
6		TELE:Zoom in the image
7		WIDE:Zoom out the image
8		Open/set,confirm the setting of parameters, open or enlarge the aperture
9		Return/Close:Return or cancel while setting parameters of the menu,close or decrease the aperture
10		Upward, set function or add parameter. Tilt the PTZ upward
11		Rightward, select the parameter whose value will be changed. Add the value of the parameter. Pan the PTZ right
12		Leftward, select the parameter whose value will be changed

13		Downward, set function or reduce the value of the parameter. Tilt the PTZ downward
14		Confirm key
15		Return/Close : Return or cancel while setting parameters of the menu, close or decrease the aperture
16		Multimeter interface
17		The charge indicator:It lights red while the battery is being charged. As the charging is complete, the indicator turns off automatically
18		The RS485 data transmission indicator: it lights red while the data is being transmitted
19		The data received indicator:It lights red while the data is being received
20		The power indicator:It lights green while the tester is powered on by the adapter

## Top interface



## Bottom interface



21 TDR cable test interface

22 SDI input (BNC interface)

23 RS485 Interface: RS485communication for the PTZ

24 HDMI IN

25 Video signal output (BNC interface)/cable tracer interface

26 CVBS input /AHD /TVI/CVI Coaxial interface

27 Optical power meter interface

28 PoE power supply output or LAN test port (Use to test PoE or non-PoE IP camera)

29 PSE power sourcing equipment.Test PoE voltage/LAN test port

30 DC 12V 2A power output , for provisional DC power supply

31 LED lamp

32 Visible red laser source emits interface

33 Power

34 DC 12V 2A charging interface

35 Audio input

36 Audio output and earphone interface

37	Microphone
38	USB 5V 2A power output (used only for power, not data)
39	UTP cable port: UTP cable tester port/ Cable tracer port
40	Micro SD card moveable
41	HDMI output interface
42	TDR cable test RJ45 port

## 3. Operation


### 3.1 Installing the Battery

The battery main switch at the right-bottom corner of tester bottom.


“0”: Battery power off

“1”: Battery power on


The tester has built-in lithium ion polymer rechargeable battery, the tester's bottom power should turn to “0” for safety during transportation (the factory default is “0”).

Using the instrument, please switch power button to “1”, press the  several seconds can turn on/off tester. In general, user no need to turn on battery switch. if don't use the instrument in long time, please turn off the switch.




Notice: please use the original adaptor and connected cable of the device!  When the battery icon is full or the charge indicator turns off automatically, indicate the battery charging is completed.



Notice: When the Charge Indicator  turns off, the battery is approximately 90% charged.

The charging time can be extended for about 1 hour and the charging time within 12 hours will not damage the battery.



Notice: Press the key  several seconds to restore the default settings when the instrument works abnormally.


Multi-meter: the red and black multi-meter pen must insert the corresponding port.



Warnings: Instrument communication port is not permitted access circuit voltage over 6V, otherwise damage the tester.



Warnings: Not allow insert multi-meter pen in the current terminal to measure voltage.





## 3.2 Instrument connection

### 3.2.1 IP camera connection

Power an IP camera with an independent power supply, then connect the IP camera to the tester's LAN port, if the link indicator of the tester's LAN port is green and the data indicator flickers, it means the IP camera and the tester are communicating. If the two indicators don't flicker, check if the IP camera is powered on or the network cable is not functioning properly.



**Note:** 1) If the IP camera requires PoE power, then connect the IP camera to the tester's LAN port. The tester will supply PoE Power for the IP camera. Click on the icon labeled POE to turn the PoE Power off or on.

2) If use the tester's menu to turn off the tester's PoE power supply, the PoE switch and the power sourcing equipment are allowed to connect to the tester's PSE port, and the PoE power will be supplied to the IP camera by the tester's LAN port. On this condition, the tester cannot receive data from IP camera, but the computer connected to the PoE switch can receive the data via the tester.



**Warning:** PoE switch or PSE power sourcing equipment only can be connected to tester "PSE IN" port, otherwise will damage the tester.

### 3.2.2 Analog camera connection



- (1) Connect the camera's video output to the tester's VIDEO IN. The image will display on the tester after pushing the PTZ icon.
- (2) Tester's "VIDEO OUT" interface connects to the Video input of monitor and optical video transmitter and receiver, the image display on the tester and monitor.
- (3) Connect the camera or the speed dome RS485 controller cable to the tester RS485 interface, (Note: positive and negative connection of the cable).

### 3.2.3 HD Coaxial camera connection

SDI/EX-SDI, CVI, TVI, AHD camera are classified as HD coaxial cameras. Hereby the following instruction of how to connect SDI camera to the tester is also applied to CVI, TVI, and AHD camera.



- (1) Connect the SDI camera's video output to the tester's "SDI IN" interface, the image will display on the tester. The tester only come with SDI input interface. There is no SDI output interface.
- (2) Connect the SDI camera or the speed dome RS485 controller cable to the tester RS485 interface, (Note: positive and negative connection of the cable).


### 3.2.4 HDMI IN





DVR or other device's HDMI in port connect to tester's HDMI in port, the meter will display input image.

## 3.3 OSD menu

Press the key  2 seconds to turn on.

Press the key  again to turn off.

short press the key  to enter sleep mode, press it again to test.

If tester works abnormally and cannot be turned off , Press the key  several seconds to turn off, the tester reset.

### 3.3.1 Drop-down Menu

Press and slide at right top right corner twice to open shortcut menu. The shortcut menu includes POE power output, IP settings, Wi-Fi, HDMI IN, CVBS, Video OUT, LAN, Brightness, settings,etc.



**HDMI:** Click HDMI IN to enter,in HDMI IN mode, It can converter test from analog to digital with dual test window IP & HDMI IN or Analog & HDMI IN.

**CVBS:** Click icon “CVBS “to enter, you can test IP and analog camera at the same time.

**Video OUT:** Click Video OUT to enter floating window, connecting the BNC cable to tester and appears analog video monitor interface, it can test circuit and BNC cable whether normal.

**LAN:**Display network port or WIFI connection real-time upload and download speeds and other network parameters.

**Brightness:** Set brightness.

**Settings:** Enter settings interface.


**IP:** Enter IP Settings interface.



**POE power output:** Turn on or off the tester “PoE power “app.


**WLAN:** Turn on WLAN net and displays current WLAN status.

**3.3.2 Short cut-menu**

You can call shortcut menu by press tester’s “menu” key, you can self- define shortcut menu.



Press the key”  “, you can turn on it, and switch functions, then press  to enter app, tap other area on the screen, to exit the menu.



Short cut-menu setting, you can long press any app in the all applications list,it will auto move to shortcut menu.If delete any app in the shortcut menu,please select a app and press several seconds,it will be deleted.

### 3.3.3 Screen capture


Long press the key “enter”, can capture screen interface and save it in any time.



### 3.3.4 Link monitor


Tap icon "Link Monitoring" at left corner on the screen, to enter.


It can detect instrument port rate 10/100/1000M, signal quality detection, upload and download speed, etc. in real time. It can be used to detect whether the network video access bandwidth of devices such as NVR is normal.



### 3.3.5 TesterPlay


Mobile screen projection (Only for android version) .


The meter creates WIFI hotspot, connect mobile phone to the tester's WIFI hotspot, or the tester and mobile phone connect to the same Wi-fi network. Tap icon “”, then select “TesterPlay” app to enter, the meter generates two-dimensional code, Please use mobile phone scan it, then download and install the client software, you can view the screen real-time projection.




PC screen projection


Install VLC player in the PC, turn on the VLC player "Media - Open Network Streaming", and input the RTSP address of on the top instrument two-dimensional code, click "play" to view the screen real-time projection. (you also can install “VLC player” in the mobile phone, tester and mobile phone display at the same time) .





### 3.3.6 IP discovery

Press IP discovery , tester auto-scan the whole network segment IP, as well as auto-modify the tester's IP to the same network segment with the scanned camera's IP.



**Local IP:** Tester's IP address, Tester can auto-modify the tester's IP to the same network segment with the scanned camera's IP.

**Discovery IP:** Connected tester equipment's IP address. If the camera connected to the tester directly, tester will display the camera's IP address, if tester connects to Local Area Network, it displays the current IP address.

**Start:** PING function, Click "Start", can PING camera's IP.

**ONVIF:** Rapid ONVIF Quick link.





**IPC TEST:**IPC TEST Quick link.

**Applicability:** Using IP discovery app,you don't need to know the first two digits of camera's IP address, it can auto-scan the whole network segment IP, and auto-modify tester's IP address,greatly improved engineering efficiency.

### 3.3.7 ONVIF test


ONVIF can display 4K H.264 camera image by tester mainstream, one key to activate camera.

Press  enter ONVIF function, the meter auto scan all ONVIF cameras in different network.




segments. It lists cameras name and IP address on the Left of screen. Tester can auto login camera and display camera image. Factory default use admin password to auto login, if you modified the password, then default use the modified password to log in.

If you select ONVIF Rapid mode, the meter automatically scan different network segments for ONVIF cameras. It lists the camera name and IP address on the Device List. Tester can auto login camera and display camera image.



Click the button “Refresh”, tester will scan the ONVIF camera again. Click the newly displayed ONVIF camera on the “Device List”. The tester will show the IP camera’s relative information and settings.

Pop-up settings menu when click the “ONVIF setting” icon in the upper left corner.



**Across network segments scan:** After open this function , enter “Setting - IP Settings - Advanced”to add other network segments IP, Rapid ONVIF function can across network segments to scan camera’s IP.

**Auto Login:**After open this function, tester can auto login camera and display camera image. (The login password is the same with last time, the first time using password is the default password "admin").

**Video transmission protocol:** UTP and TCP protocol.

**Open password cracker:**Cracks password of cameras.

**View manual:**Open Manual.


**Restore Defaults:** Revert “Rapid ONVIF” to default settings.

**Confirm:**Save the modified parameters.


Click “MENU” icon to open camera setting.




While in the “Live video” menu, click “Video Menu” at the top right of the image to access the following tools: snapshot,record, photo, playback, PTZ and settings.




**ONVIF PTZ control:** Tap the image in the direction you want the PTZ camera to move. Tap the left side of the image to move left, right to go right, up to go up and down to go down. Compatible IP PTZ cameras will rotate accordingly. PTZ rotation direction is displayed on top left corner of the image.




**IP camera video settings:** Click “Video Set” to enter the IP camera’s encoder and resolution settings. Make the desired changes and click “OK” to save.




**Image setting:** Click “Imaging Set” to adjust image brightness, saturation, contrast, sharpness and backlight compensation mode.




**Profiles:**Click “profiles”,can view video streaming current configuration files, as well as switch between Major stream and minor stream.



**Preview pictures:**Quickly preview and zoom in or out pictures, automatically and manual refresh.



**Identification:** Click “Identification” to view information of the camera.



**Time set:**Click “Time set”,select "Manual set" to set up the time of camera.

ONVIF

Logged in adminin Login Out

Device List(29)

SN 22  
192.168.0.245  
Location country/china

Dahua  
SN 23  
192.168.0.246  
Location country/china

Dahua  
SN 24  
192.168.0.250  
Location country/china

Dahua  
SN 25  
192.168.0.251  
Location country/china

Dahua  
SN 26  
192.168.1.114  
Location country/china

Add Refresh

setting

Device Info

Time Setting

Manufacturer

Network Setting

User Manage

Web page

NVT

Live Video

Video Set

Image Setting

Profiles

Preview

Camera Time 14:42:52 2022/3/17 (Local Time)

Time zone:  
GMT+08:00

Time Setting:  
Synchronize with computer time

System Time 06:43:03 2022/03/17

OK Restore

Time zone and system time just provide a reference for the modification of camera time, neither time zone nor system time can be changed.

1. Refer to time zone: select referenced time zone, click the Apply button, you can change the camera time.

2. Refer to system time: manual settings, a quasi time, click the Apply button, you can change the camera time.

**Maintenance:** For camera software reset or restore to factory settings.

ONVIF

Logged in adminin Login Out

Device List(29)

SN 22  
192.168.0.245  
Location country/china

Dahua  
SN 23  
192.168.0.246  
Location country/china

Dahua  
SN 24  
192.168.0.250  
Location country/china

Dahua  
SN 25  
192.168.0.251  
Location country/china

Dahua  
SN 26  
192.168.1.114  
Location country/china

Add Refresh

setting

Device Info

Time Setting

Manufacturer

Network Setting

User Manage

Web page

NVT

Live Video

Video Set

Image Setting

Profiles

Preview

Software Reset

Software Reset

Restore Factory Setting

Hardware Reset

Reboot

Reboot

Description:

Software Reset

When camera system abnormally is caused by other reasons, use this function to restore factory default system, but user data and settings will not be deleted but kept.

Restore Factory Setting

Clear camera data, restore to the factory default initialization status.

Reboot

Successfully rebooted, the device is rebooting!

**User Set:** Modify camera user name,password, etc. parameters.

ONVIF

2022-17-03 06:43:15

Logged inadmin

Login Out

Device List(29)

SN 22  
192.168.0.245  
Location country/china

Dahua  
SN 23  
192.168.0.246  
Location country/china

Dahua  
SN 24  
192.168.0.250  
Location country/China

Dahua  
SN 25  
192.168.0.251  
Location country/China

Dahua  
SN 26  
192.168.1.114  
Location country/china

Add Refresh

setting

Device Info

Time Setting

Manufacturer

Network Setting

User Manage

Web page

NVT

Live Video

Video Set

Image Setting

Profiles

Preview

Username: admin

Username: admin

Password: Administrator

User Level: Administrator

Are you sure to delete this folder ? Modify Create

**Network setting:**Click “Network Set “to change the IP address. Some cameras cannot support change IP address, so there is no change after saving.

ONVIF

2022-17-03 06:43:21

Logged inadmin

Login Out

Device List(29)

SN 22  
192.168.0.245  
Location country/china

Dahua  
SN 23  
192.168.0.246  
Location country/china

Dahua  
SN 24  
192.168.0.250  
Location country/China

Dahua  
SN 25  
192.168.0.251  
Location country/China

Dahua  
SN 26  
192.168.1.114  
Location country/china

Add Refresh

setting

Device Info

Time Setting

Manufacturer

Network Setting

User Manage

Web page

NVT

Live Video

Video Set

Image Setting

Profiles

Preview

Auto Acquisition:

Disable

IP Address:

192.168.1.114

Subnet Mask

255.255.255.0

Default gateway:

192.168.1.1

Host name:

IPC

DNS Server:

223.5.5.5

NTP servers:

clock.isc.org

HTTP port:

Activate 80

Cancel

HTTPS port:

Activate 554

RTSP Ports:

Discover

ONVIF Discovery Mode:


Discover

OK Restore



goto

Note: If the ip information cannot be modified successfully, please go to the camera tool to modify



**Zoom in image:** Press the  key to enter the zoom mode. Press it again to exit zoom mode. When the image is enlarged tap left, right, up or down on the image to move the whole image on the screen.




When the image is enlarged, if not operate on touch screen, it can operate by the keyboard, press the key  to zoom in, press the key  to zoom out, press upward and downward key to move image.

If it is network video input to the tester, as the tester supports resolution up to 1080p, the input image will be very clear after it is enlarged. This is greatly helpful for the installers to ensure the IP camera's video coverage and decide the IP camera's install site.

Image can only be enlarged on SD mode (The icon "ONVIF" is SD mode.)


Select relative function on the bottom Toolbar to operate, "Snapshot", "Record", "Photos", "Video playback", "Storage set", "PTZ control", etc.




**Snapshot:** Click bottom”snapshot” to screenshot the image and store it in the tester.

If select manual storage, appears dialog box “Input Name”,user-defined the files name (by Chinese character, English letter or digit) to save in the tester, if select “Auto- storage”,the tester auto stores the files after snapshot.


**Record:**When you click bottom the “Record” icon, video starts recording. A red recording icon appears on the screen and begins to flash and a timer appears indicating the time elapsed for the video. Click on the “Stop” icon to stop recording and save the video file in the tester.



**Playback:** Click the “Playback” icon to view saved videos. Double click the video you want to play. Click to return to the last menu.



To rename or delete a photo, click and hold on the file until this screen appears:



Video files can play in the Video player on the main menu.

## PTZ

Set preset position: Move the camera to preset position, enter the preset number on the bottom right corner to complete position preset.


Call the preset position: Select the preset number on the left, click "Call" to call preset.



PTZ Speed set:Horizontal and vertical speed set.




**Modify channel name:** clicking "OSD" will pop up OSD settings, including time, channel name and other optional items.





**RTSP:** Get RTSP address of the current camera.

**Doc:** Auto create testing reports document of camera, click "Create document". Click Preview to view the report document.



Enter the camera test information, click "Create Document" to complete the report.

Enter simple message

Create documents

Job/Project name:

Operator:

Customer name:

Company:

Location:

Address:

Tel/Email:

choose photo

\*\*can skip

Click "Doc" menu again, you can preview the report document.

← 2017-06-20-08-39-07.pdf

IPC-TESTER		Report	
Project name :		Operator :	
Customer name :	tyhh	Company :	ghnij
Location/Building :	gyhh	Address :	
Test Time/Date :	2017-06-20 08:38:58	Tel/Email :	
<b>Camera Device Info</b>			
Camera name :	2CD3T45-I3	Camera Model :	DS-2CD3T45-I3
Camera time :	2017-6-20 16:40:3		
<b>Network Info</b>			
Ethernet port speed :	100Mb/s	Duplexity :	Full
Camera IP address :	192.168.0.64	Camera subnet mask :	255.255.255.0
Gateway :	192.168.1.1	MAC address :	c4:2f:90:73:a8:0e
DNS :	8.8.8.8		


**Icons description:** the description of function icons on the bottom toolbar.

3.3.8 Test tool


Test tool is developed for installation and debugging of the IP camera, it can display image, and modify IP, user name and password etc. Making camera test more convenient and quickly.

Click the tool icon to enter test tool.


**Activation:** select left [online detection] to display the "unactivated" camera and click activate.




Activate and Batch activate are optional, support reserved phone number for resetting password.



**Play:** When mode display “activated” camera, input correct password, click “Play” popping up “private protocol” and “ONVIF”, Select correspond protocol to view the camera image.



**Modify Channel:** Click “Modify Channel”, will pop up OSD setting, includes time, channel name, etc.







After selected Channel name, can edit channel name, modify the display position and font size. If select “Default position” of Content location, then no need to modify. If select “customize”, then can modify Channel name and display position, click “OK”to view the image. Click “Back” or “Return” button to return previous interface.




**Modify Network:** Support Modify and batch modify two way, can modify camera IP address, Subnet mask, gateway.




Input new IP address, need to input password, click “OK” to save the modification.




**Modify user information:** modify camera user name and password, which is onvif, test tool, IPC TESTE user name and password, not web user name and password.




Factory reset setting: camera will be soft reset, and the device's user name, password and network set be saved. Other settings information is factory reset.




Reset password: Click "reset password", scan the pop-up QR code, will send the result to reminder email, then will receive the safety code to reset the camera password.





### 3.3.9 IP camera test


Display image from the 4K camera by main stream

Click icon  to enter IP camera test



Note: Currently, the Test App only supports some brands' specific IP cameras, these include specific models made by ACTI, AXIS, Dahua, Samsung, and many more. If the camera is not fully integrated, please use the ONVIF or RTSP apps.


IPC test interface




**Local IP:** This is the tester's IP address. Click "Edit" to enter "IP setting" and change the tester's IP address settings.

**IP camera type:**Click on the IP Camera type to select the Manufacturer and model number of the integrated IP camera.

**“Manual”:**Click IP camera type, list Honeywell,Kodak,Tiandy, Aipu-waton, ACTi, WoshiDA IP camera, etc. If the brand has offered official original protocols, please select camera type, input IP camera address ,user name and password ,click” official” to enter the camera image display interface(Currently, only support DAHUA official protocols ).



**Stream code:** When test camera via RTSP, you can select mainstream or sub stream to test (if camera's RTSP have not been start or without, it will tip “auto match fail, please witch to manually selecting.




**IP Camera's IP:** Enter the IP camera's IP address manually or click "Search" to auto-scan for the IP camera's IP address. It is better to directly connect the IP camera to the tester so the search results will only display the camera's IP address. If the tester is connected to a PoE switch, it will find and display several IP address.

**IPC User Name:** Enter IP camera's user name.


**IPC Password:** Enter IP camera's login password.


**IPC Port:** When you select the IP camera type, it will default the camera's port number and doesn't need to be changed.

After all settings are completed, click "Enter" to view the live video.



If IP address setting has error or IP camera is not connected. The tester prompts "Network Error".


Click  to quit from image display and return to the Tester interface.

 Once you are viewing video on the Tester app, you will see the "Video Menu" icon on the top right. This button will give you access to snapshot, record, photo, playback, PTZ, and set. Please refer to the ONVIF section to use these functions.

### 3.3.10 Virtual IPC


Virtual IP Camera function, simulating ONVIF camera to send video stream, used to test NVR, monitor transmission channel and IP camera, supports wired network and WiFi.

After network connection, the virtual IP camera will auto turn on and simulate ONVIF camera to send video stream.



After function turned on, you can preview the ONVIF video sent by the tester on NVR or installing ONVIF tools and VLC player in computer terminals.

When network connection disconnected or application exit, the virtual camera function will auto turned off.



#### Practicability:


A. When IP camera appears abnormal image, this function can be used to replace the camera. If the

image is normal after replacement, the IP camera is in problem.

B. When maintaining IP cameras, this function can be used to send ONVIF video stream to the monitoring center. If the monitoring center can watch the video sent by the tester, the video transmission channel is normal.

C. When installing and maintaining the NVR but without IP camera, this function can be used to simulate an ONVIF IP camera.

### 3.3.11 HDMI IN

HDMI in HD signal test, Tap icon “” to enter

When tester receives HDMI in image, the top tool bar shows the resolution of this image. You can select “resolution” to set resolution in the setting menu .Tap screen by twice, full image display. Support resolution below

4K\_3840×2160-30FPS/2K\_2560×1440P/720×480p/720×576p/1280×720p/1920×1080p/1024×768p/1280×1024p /1280×900p /1440×900p




#### (1) Snapshot

Click the icon “Snapshot”, when the video in, to take a picture and save the current video frame in the tester as JPEG file.

If the unit is set to the manual mode an “Input Name” pop up box will appear and you can enter a title for the snapshot. If the unit is set up to automatically set file names, this box will not pop up.





## (2) Video record

When you click the “Record” icon, video starts recording. A red recording icon appears on the screen and begins to flash and a timer appears indicating the time elapsed for the video. Click on the “Record” icon again to stop recording and save the video file in the tester.


If select manual storage, before recording begins,appears dialog box “Input Name”,user-defined the files name (by Chinese character, English letter or digit) to store in the tester,tester will hereby store the files after recording.



### (3)Photo


Click the icon “photo” to enter, click the selected thumbnail photo to display it on the screen.

Double-tap the image can view full screen. Double-click again the photo to return.




To rename or delete an image, click and hold on the file until this screen below appears.




Click  to close and return to PTZ controller.

#### (4) Recorded video playback

Click the “Playback” icon to view your recorded videos. Tap on the video file image you want to watch.



To rename or delete a video, click and hold on the file until this screen appears:



Video files also can play in the main menu “Video Player”.


### 3.3.12 Video monitor test (CVBS)

Analog camera test and PTZ control, click icon



to enter



Display the input video image, click the top menu bar icon  to enter video level meter (PEAK level, SYNC level, COLOR BURST measurement)


Select relative function on the right side Toolbar to operate, functions including “Photos”, “Snapshot”, “Record”, “Playback”, “PTZ”, “Set”,

Click , to quit.

Click the screen twice quickly, can be full zoom in on the touch screen.

#### (1) PTZ controller parameter setting

Select and click icon “PTZ” to enter PTZ setting:



#### A. Protocol

Use the up and down arrow keys to move the yellow cursor to the “protocol”, set corresponding Protocol and support more than thirty PTZ protocols. Such as Pelco-D,Samsung,Yaan,LiLin,CSR600, Panasonic,Sony-EVI etc.

#### B. Port

Click and move, to “port” Select the communication port for the PTZ camera controlling (RS485) .

#### C. Baud

Move the yellow cursor to “Baud”,select the baud rate according to baud rate of the PTZ camera. (150/300/600/1200/2400/4800/9600/19200/57600/115200) .

#### D. Address

Set the ID according the ID of PTZ camera (0~254), the setting address data must be consistent the speed dome address.

**E. Pan speed:** Set the pan speed of PTZ camera (0~63)

**F. Tilt speed:** Set the tilt speed of PTZ camera (0~63)

#### G. Set preset position (Set PS)

Click and select “Set PS”, set and save preset position number(1~128).

#### H. Call the preset position (Go ps)


Click and select “Set PS”, set and save preset position number (1~128), click “sure” to save,  
Call some special preset number, can call the dome camera menu.



Check and set the protocols, address, interface and baud, all must be consistent with the dome camera, then the tester can test .After setting the parameter, the tester can control the PTZ and lens.



To control PTZ by screen touch:

Tap left, right, upward and downward on the touch screen to control the PTZ rotation direction. By two fingers move outward and inward on the touch screen to zoom in and out the PTZ.



### PTZ Control:

Press the key   control the PTZ direction of rotation.

Press the key  or  , to switch on or turn off the aperture.


Press the key  or  , adjust the focus manually.

Press the key  or  , manually adjust the zoom.


### (2) Video and storage setting

Click icon “set”,to enter and set analog video image brightness,contrast, color saturation, as well as the file storage way after snapshot and recording, support auto-storage and manual storage.

When select manual storage, user can name and store the files.




### (3) 4 x zoom image display and Video out

When image input, press  to enter “zoom”, press it again to quit.

Using the touch screen to control PTZ camera movement:

Tap left, right, upward or downward on the video image to move the PTZ camera in a desired direction.



Stretch two fingers outward or inward on the touch screen to zoom the image in or out.

If not use touch screen to operate, press the key **TELE+** to zoom out, press the key **WIDE-** to zoom in, press upward and downward key to move the image.



For analog video input, as the resolution is 720\*480, it is normal that the zoom in image is not clear. But for network digital video input, as it supports resolution up to 1280\*960, the zoom in image is still very clear. This is very helpful for IP camera installation.

#### **(4) Snapshot**

Click the icon “Snapshot”, when the video in, to take a picture and save the current video frame in the tester as JPEG file.

If the unit is set to the manual mode an “Input Name” pop up box will appear and you can enter a title for the snapshot. If the unit is set up to automatically set file names, this box will not pop up.

#### **(5) Video record**

When you click the “Record” icon, video starts recording. A red recording icon appears on the screen and begins to flash and a timer appears indicating the time elapsed for the video. Click on the “Record” icon again to stop recording and save the video file in the tester.


If select manual storage, before recording begins ,appears dialog box “Input Name” ,user-defined the files name(by Chinese character, English letter ,or digit) to store in the tester, tester will hereby store the files in the tester after recording . if select “Auto-storage ,tester will auto store the files in the tester after recording.



## (6)Photo


Click the icon “photo” to enter, click the selected thumbnail photo to display it on the screen.


Double-tap the image you want to view to make it full screen. Double-click again the photo to return.



To rename or delete an image, click and hold on the file until this screen below appears







Click  to close and return to PTZ controller.

### (7) Recorded video playback

Click the “Playback” icon to view your recorded videos. Tap on the video file image you want to watch.





To rename or delete a video, click and hold on the file until this screen appears:




Video files also can play in the main menu “Video Player”.

**(8) Video level meter**

Click the icon  to enter, the Integrated Mount Tester has adopted hardware high-speed sampling and processing technology, can perform both NTSC and PAL video amplitude signal measurements for PEAK to PEAK, SYNC levels and COLOR BURST chroma level. When an analog signal is fed into the meter, the tester displays the measurements on the bottom left corner of the screen.



While in PAL format, the unit will be mV, While in NTSC format, it will be IRE.



NTSC	Video signal level	140±15IRE
	Chroma level( COLOR BURST)	40±5IRE
	SYNC signal level	40±5IRE
PAL	Video signal level	1000±200mV
	Chroma level( COLOR BURST)	300±35mV
	SYNC signal level	300±35mV

**Video signal PEAK to PEAK level:**

For NTSC format, the video signal level is 140±15IRE

For PAL format, the video signal level is 1000±200mV

If the level is too low, it will cause the image to lose quality and limit the distance it will travel over cable. If the level is too high, it will distort the image.

**SYNC level:** Tests the amplitude of the video sync pulse to verify if the video level is correct.

For NTSC format, the SYNC level is 40 ± 5IRE

For PAL format, the SYNC level is 300 ± 35mV

If the level is too low, it will cause the image to not frame out properly. If the level is too high, it will lead to a poor quality image.

**COLOR BURST level:** Testing the color burst level will determine if the burst signal is sufficient to trigger the displays color producing circuit. Burst will diminish in amplitude over longer cable runs and can get fall below the threshold for the video display to show a color image.

For NTSC format, the Chroma standard level is 40 IRE.


For PAL format, the Chroma standard level is 280mV.

If the Chroma level is too low, the color will not be as deep, and some details of the image will become lighter. If the Chroma level is too high, there will be distortions on the image. If the coaxial cable is too long, it will reduce the chroma level.

Image loop test: Test video optical transmitter and receiver and video cable, connect one end to the tester "VIDEO OUT" port, and the other end connected to "VIDEO IN" port, the signal send via "VIDEO OUT" port, and received via "VIDEO IN" port, If the testing is ok, the tester displays several gradually dwindling photos on the desktop.

### 3.3.13 SDI/EX-SDI Camera Test

SDI camera test, Dome camera test and PTZ control, click icon  to enter.



When tester receives SDI camera image, it will display the image data.

Double-taps on the screen to make the image displayed full screen.

The tester supports resolution as follows:

HD-SDI: 1280x720P 25/30/50/60 FPS, 1920x1080P 25/30 FPS, 1920x1080I 50/60 FPS


EX-SDI:3840x2160P 25/30 FPS,2560x1440P 25/30 FPS,1920x1080P 25/30/50/60 FPS,

1920x1080I 50/60 FPS,1280x720 P 25/30/50/60 FPS





The tester's HDMI output port can be used as SDI to HDMI converter, output HD SDI image to HD TV monitor.

Select relative function on the right side Toolbar to operate, “Snapshot”, “Record”, “Photos”, “Video playback”, “PTZ control”, “Video Brightness and Storage set”, the operation is the same to the video monitor function, please refer to the relevant instructions “3.3.1” in the manual.

Click  , or press **MENU** to quit.

### 3.3.14 CVI camera test

HD CVI camera, CVI dome camera test and PTZ control, click icon  to enter.




When HD CVI signal input, the tester will display the image resolution on the top bar. Double-taps on the screen to make the image displayed full screen.

The tester supports resolution as follows:

2MP@25/30fps ; 4MP@25/30fps; 5MP@25/20fps; 6MP@20fps; 4K@12.5/15/25/30fps.

If test 5MP, 6MP and 8MP camera ,please go tester app"Auto HD " for tesing.




#### (1)PTZ control


##### 1.1 Coaxial PTZ control

Click the icon"PTZ"on the right toolbar to do the corresponding setting.

"Port": select coaxial control



Enter PTZ address to perform parameters setting.



Operation instructions, please refer to “3.3.1 PTZ (1) Video monitor test”.













The PTZ address in the tester must be consistent with the dome camera or decoder, then the tester can test .After setting the parameter, the tester can control the PTZ and lens.



To control PTZ by screen touch:


Tap left, right, upward and downward on the touch screen to control the PTZ rotation direction, PTZ cameras will rotate accordingly. By two fingers move outward and inward on the touch screen to zoom in and out the PTZ.

To control PTZ by key buttons

- ◆ Press arrow keys to control     to control the PTZ direction of rotation
- ◆ Press the key   to switch on or turn off the aperture.
- ◆ Press the key   , adjust the focus manually.
- ◆ Press the key   , manually adjust the zoom.

## Set preset position

Setup preset position: move the PTZ camera to the preset position, then Tap it and input preset position number. Tap “Set position” to complete set preset position.






## Call preset position

Tap the preset position:

Tap the preset position area, input preset position number. Tap “call position” to complete call preset position.




## 1.2 RS485 control



Operation instructions, please refer to “3.3.1 PTZ (1) PTZ control parameters setting”.

### (2)Coaxial amera OSD setting





Tap icon “UTC”, select “menu setting” to enter the dome camera menu.




Input calling dome camera menu address code, after finishing the parameter settings, you can press the


key  or click the icon  to call the dome camera menu .



Press arrow keys     to set.

(3) Snapshot, record, photo viewer and video play back, please refer to “3.3.12 PTZ (1) Video monitor test”.

Tap ”close menu” or press the key ”  ”to close camera menu.



#### (4) Save setting

Click icon “Set” on the right toolbar to enter storage setting.


Support auto-storage and manual storage.

When select manual storage, user can name and store the files.

Focus information: Select enable, will display the focus information and image quality on bottom left corner of interface.

Len simulation: Select enable, simulating the display area of different lens sizes of 2.8 /3.6 /4 /6 /8 /12 /16 /25mm.


Audio: Select enable, support CVI audio test



### 3.3.15 TVI camera test



TVI camera, TVI dome camera test and PTZ control, Click icon to enter.



When TVI signal input, the tester will display the image resolution on the top bar. Double-taps on the screen to make the image displayed full screen.

The tester supports resolution as follows:


2MP@25/30fps ; 4MP@25/30fps; 5MP@12.5/20fps; 4K@12.5/15fps.


If test 5MP and 8MP camera ,please go tester app"Auto HD " for tesing.



## Coaxial camera menu settings

Tap icon “UTC”, select “menu setting” to enter the dome camera menu.




Input calling dome camera menu address code, after finishing the parameter settings, you can press the key **ENTER** or click the icon  to call the dome camera menu.



More operation instructions (such as PTZ control, Coaxial camera OSD setting ,snapshot, recording and playback etc), please refer to "3.3.6 CVI camera test".

### 3.3.16 AHD camera test

AHD camera, AHD dome camera test and PTZ control, Click icon  to enter.




When AHD signal input, the tester will display the image resolution on the top bar. Double-taps on the screen to make the image displayed full screen.

The tester supports resolution as follows:


2MP@25/30fps ; 4MP@25/30fps; 5MP@12.5/20fps; 4K@15fps.

If test 5MP and 8MP camera ,please go tester app"Auto HD " for testing.



(1) Coaxial PTZ control

UTC control : select “PTZ control or PTZ control-2”(AHD camera has two different order ,if select “PTZ” cannot control,please go “PTZ-2” ) .



If to coaxial PTZ control the AHD camera, no parameters setting is needed.

**More operation instructions please refer to “3.3.14 CVI camera test”.**

### 3.3.17 AUTO HD

Auto-recognize the resolution and Auto-display the image of the connected camera. Support coaxial PTZ control and call OSD menu, support up to 8MP CVI/TVI/AHD/CVBS cameras.



Coaxial camera OSD setting

Tap icon “UTC”<sup>④</sup>, select “menu setting” to enter the CVI/TVI/AHD/CVBS camera menu.

Input calling dome camera menu address code, after finishing the parameter settings, you can press the

key “Enable” or click the icon  to call the dome camera menu .

Take the camera to CVBS mode as an example, click the PTZ option on the right, select "Coaxial Control" for "port"; select "Menu Setting" for "Coaxial Control Option". Click "Enable" to open the CVBS camera menu.






Press arrow keys     to set, Press  to confirm.



### 3.3.18 Cable Test

Click icon  to enter



Test LAN cable or telephone cable.

Connect LAN cable or telephone cable with the CCTV tester and cable tester. And then the connecting status, cable type and the sequence of wires as well as the serial number of the cable tester kit will be displayed.

The number of the cable tester is 255.

If need several different number other types cable testers, should pay the additional cost.

#### Visual judgment of network cable availability:

- ☒ All sequence of cable is correct, generally corresponds to Gigabit straight/cross network cables.
- ☒ Cable sequence is wrong, but the cable is still available, generally corresponds to 100M straight-through/cross network cable.
- ☒ All sequence of cable is wrong, not available.


#### Meter-end/cable tester-end fault location:

Tester-end/cable tester-end display “x”, it means the RJ45 cable connector or within 1 meter from the RJ45 cable connector is faulty.

The middle part of sequence display “x”, it means the RJ45 cable connector at the end of Tester/Cable tester is normal, and there is a breakpoint 1 meter away from the RJ45 cable connector.


The middle part of sequence is not communicated and not display “x”, it means the RJ45 cable connector at the end of Tester / Cable tester is faulty, and the middle of the cable is normal.

Tester-end can perform RJ45 cable connector fault detection even when the remote end is not connected to the cable tester's UTP interface.




### Short-circuit detection:

Supports short-circuit detection of the network cable. Tester can perform short-circuit detection even when the remote end is not connected cable tester or cable tracer.




### Cable test

Tap "cable test sketch map", pop up Straight-through cable and crossover cable sketch, It is for line sequence reference, when the crystal on the first pressure in the twisted-pair.



3.3.19 RJ45 cable TDR test

Connect cable to tester’s LAN port, click icon  to enter RJ45 cable TDR test app.




**Single test:** test cable status, length and attenuation.

**Repeat test:** continue to test cable status, length and attenuation.

**Status:** after link up, screen display “online”, if not link up or open circuit, screen display “open circuit”, if cable pair is short circuit, screen display “short circuit”.

**Length:** the max test length is 180 meters, when cable is open circuit or short circuit, can test the cable length, if screen display “online”, the testing result would be not accurate.

**Cable quality test:** Green is good quality cable, Yellow is Poor quality cable, Red is water poured cable, the attenuation value will be displayed when cable over 10 meters.



**Advanced Test:** test cable pair status, length, attenuation, reflectivity, impedance, skew and other parameters.


**Attenuation reflectivity:** after link up, if reflectivity value is 0, it is the best quality communication.

**Impedance:** after link up ,if the impedance value is 100  $\Omega$  ,it is the best quality communication, the range is generally in 85-135  $\Omega$  .


**Skew:**after 1000M link up, when skew value is 0ns,it is the best quality communication, if over 50ns, will cause a Bit Error Rate in the transmission

**Cable sequence diagram:**

A straight-through and cross-over cable diagram, the cable sequence display for reference.




Click “Help”, check the instruction of all parameters.



### 3.3.20 Cable Tracer

Connect test cable or BNC cable to the UTP port or the UTP/SCAN (VIDEO OUT) port on the bottom.

Click icon  to enter.



UTP mode is used for searching the normal network cable or other cables. STP mode is used for searching the shielded network cable.

Rotating the switch of cable tracer to turn on. Clockwise rotation increases sensitivity, anticlockwise rotation reduce sensitivity.

Use the blue Combination cable identifier and network cable tester's Probe to touch all the cables in the bundle.

You are searching at the other end. The cable that gives off the loudest tone is the cable connected to the tester. Press the + or – buttons on your blue cable identifier to adjust the volume.



**Note: Install two AA batteries in your blue Cable Identifier.**

Cable tracer and Cable tester can be tested at the same time. It is better to judge whether the search network cable is accurate. Connect the other end of the tested network cable to the “UTP” port of cable tracer, the cable sequence, continuity, test box number and network cable type will be displayed on the right side of the meter interface. The “G” indicates the continuity of the shielded network cable.

The 1-8 indicators of cable tracer will flash according to the cable sequence. The DIRECT / CROSS / OTHER three indicator lights display the type of network cable directly.

Press the "MUTE" button of cable tracer for 2 seconds. After the "Di" sound, the silent mode is turned on. In the silent mode, can judge cable type according to the indicator light. Press the "MUTE" button again to exit the silent mode.

### **Application**

It's convenient for people to find out the other end of the cable from the messy cables in security maintenance and network engineering.

While searching BNC cable, connect one port of the alligator clips to the copper core or copper net of the BNC cable, the other one to connect the earth wire (barred windows).



**Note: The battery of the cable tracer must according to corresponding positive pole + and negative pole -, otherwise will damage the tester.**

## **3.3.21 TDR3.0 cable test (\*optional)**

### **Note:**


The testing cable can't be connected to any equipment, otherwise it will damage the tester!

Connect Alligator clip cable to the TDR port, Alligator clips red and black clips are clamped to the metal cores of the cable being tested, and should connect well before testing, otherwise it will influence the accuracy.


### **1. Breakpoint and short circuit test**



Click the icon in [Network&Cable] to enter the TDR breakpoint and short circuit measurement function application, the meter built-in BNC cable, network cable, RVV control cable, telephone cable, TVVB elevator video cable and other cable testing options. Users can define their own calibration cable type. Click on the "cable name" dialog box, slide your finger up and down to select the type of cable to be tested, click on "Length Test" to measure, and the meter will measure once per click.




The network cable or telephone cable with RJ45 connector can be connected to TDR RJ45 port on the bottom of meter for testing. Select cable type "UTP CAT 5E (4 pairs) or UTP CAT 6E (4 pairs)" for testing.



Short detection: When selecting the cable type "UTP CAT 5E/6E (4 pairs)", short-circuit detection is performed on the 1-8 cores of the network cable.





## 2. Curve trajectory

### (2.1) Curve mode selection

Auto: default parameter, default auto mode every time you start the program. Auto mode will match with the test length of the best long line or short line mode measurement curve.

Note: If you use a mode that does not match the actual length, it may cause abnormal test results and curves.

### (2.2) curve trajectory analysis

The inflection point in the curve, that is, the location of the break point or short circuit of the cable under test.

Inflection point: curve after a period of smooth curve suddenly rise or fall at.

Curve in the inflection point after an upward trend, is a short circuit; curve in the inflection point after a downward trend, is a broken line.

### (2.3) Operations on curve graphs

Zoom: gesture zoom, will be the center of the curve with two fingers center point to zoom

Curve move: after zooming, press and hold the curve and then drag to move the curve

Scale bar move: distance scale bar shows the length of the current position, single click on the curve chart, the distance scale bar will jump to the clicked position; or use the left and right keys to move


Curve thumbnail: click on the thumbnail to restore the scaled curve 1:1

Curve full screen: double click on the same position of the curve to turn on or off the full screen

3. Calibration


Due to differences in production processes and materials, the cable impedance of different manufacturers may be different, which will lead to large deviations in the test results. The Calibration function can be used at this time.

Calibration: Select "User-defined" in the "Cable Name".



Select a cable of 100 to 200 meters (more than 50 meters),adjust the right side wave speed for testing, click “^” or “v” to adjust wave speed ,while display length closet the actual Length.

After adjusting the wave speed to make the result closest to the correct length, click "Adjust", enter the new cable name at "Cable name", select the corresponding cable type,and fill in the wave speed field with the adjusted wave speed, then press "OK" to save.It can be used for the same cable testing next time.




## Application


TDR test is the use of pulse reflection method, to transmit pulse signal for tested cable, when cable is open circuit or short-circuit, reflected pulse is generated, the tester receives and deals with the reflected wave, measurement results displayed on the screen. TDR can test cable open circuit and short circuit, help engineer quickly find the cable's problem location. It is more convenient and efficient to repair the faulty cable.


## Note:

The TDR reflect signal could be affected by the cable quality/ cable' s not well connected etc to cause the different TDR measurement. The TDR measurement is for reference only.


## 3.3.22 Analog video generator

Click  to enter, the tester sends the color bars from the "Video out" port, Click the icon "PAL", select "PAL/NTSC" output formats.



Click the selected color-bars, testing image or single bar (red, green, blue, white or black). Double click to full display on the screen and output, click  to return main menu.

Application



**Analog video generator:** Tester can send and receive Analog video generator through the tester's "video out and video in" port, it is for testing transmission channels, such as video optical, video cables etc. The tester "VIDEO OUT" port to connect optical terminal's sending port, and "VIDEO IN" port to optical terminal's connect its receiving port.

A. When maintaining the dome camera, the tester sends out the color bar by its BNC output to the monitor at the monitoring center. If the monitor receive the color bar, it means the video transmit channel works normally. Meanwhile, on the basis of the received color bar, the monitoring center can


judge if transmission has loss or interference.


B. The tester sends out the pure color bar (such as white and black color), to test the monitor whether has bright or black dots.

C. The tester sends out video signal image to test if the image received by the monitor has excursion.

### 3.3.23 Network tool


#### (1)IP address scan

Connect the cable to the LAN port, click icon  to enter, set your IP address search range by changing the start and end IP addresses. Click the “Start” button to scan the IP address range. You can also input an IP address in the Port Number Scan to scan for open ports.



#### (2)PING Test


Connect a network cable to the LAN port and click the icon to open the PING tool. You can set your LOCAL (native) IP address, Remote IP address (e.g. IP camera), Packet count, Packet Size, Packet time and Timeout. Press “Start” to start pinging. If the IP camera or network device is not configured properly or not plugged in, it will say “Destination host unreachable,” or have 100% packet loss. If the tester connects to the device, the send and receive packets will have a 0% packet loss.




**Application:** PING testing is the most conventional network debugging tools. It is used for testing if the connected IP camera or other network equipment's Ethernet port is working normally and the IP address is correct.

It's normal that the first data packet will be lost when test start.

### (3)Network test (Ethernet bandwidth test)

To use the Network tester, you will need two testers. One is used as a Server and the other as a Client. Both devices must be on the same network segment in order to communicate. Click the  icon to open the Network tester app.




When test, need a tester or a computer installed Network Test Software as the Server, the other tester sends packet test. The two testers must be in the same network segment.


a). **Start the server:** Click “Start Server” button to use the tester as a Server. It will display its IP address at the top of the screen.



b). **Start send packet test:** Using the other tester, type in the Server's IP address at the top right corner of the screen. This app is used to send packets for network speed testing. Click the “Start” button to send the packets and start testing.



Network bandwidth testing can also be tested with a computer using compatible network bandwidth testing software. Install network bandwidth testing software on a computer, as a test Client or Server, to do the mutual testing with the tester. If use computer as the server, the computer IP address is: 192.168.0.39.




Tester as Client, tester's IP address is:192.168.0.139. The Server and the Client are at the same network segment, but with different IP address. Input Server's IP address 192.168.0.39 in the tester and click "Start" to test network bandwidth.







Or use tester as a Server, computer as test Client(select Client, input tester's IP address to test) .




When use tester as Server, shows results:




#### (4)Port Flashing

Connect a network cable to the meter's "LAN" port, click the icon  to open the Port Flashing app. Click "Start". The Integrated Mount Tester sends a unique signal to make the connected LAN port of the switch flash.



If the tester and PoE switch are connected well, the LAN port of POE switch flash at special frequency.

If not, no any changes on the LAN port.




#### Application:

The tester will send special signals to make the connected LAN port flicker at special frequency, which will enable the installers to easily and quickly find the connected Ethernet cable. This function can prevent mistakenly insertion or disconnection non-corresponding cable to artificially interrupt network connection.

**(5)DHCP server**


Click on the DHCP icon to open the DHCP server app. Select the “Start” check box at the top and make any desired changes to the network settings. Click “Save” to start assigning dynamic IP addresses for IP cameras and other networked devices. Click the “Refresh” button to check your Client list.




**(6)Trace route**


It is used to determine path of the IP packet access target.

Note: Trace route testing results only for reference, for accurate test route tracking, please use professional Ethernet tester.


Click  to enter trace route. Input tracking IP address or domain name in the Remote Host IP. Set maximum hop count, normally default is 30.




Click “start” to trace the goal address.



**(7)Link monitor**

Click the  icon to open the Link Monitor app. This app is used to see if an IP address is occupied by other network devices. This will avoid new address conflicts.

Click “Add” and enter the desired IP address. To test different network segments, click the “Settings” icon on the main menu and go to IP Settings and make the desired changes. Once the desired IP addresses are added to the Link Monitor list, click “Start”. If the IP address status shows a check mark the IP address is occupied. If the IP address status shows an X the IP address is available. Click “Stop” to stop the testing.



**Application:**

Add an IP camera or other network device to the current network group, the new IP address must not be


occupied, otherwise it will cause IP conflicts and stop the equipment normal working. Link monitor can check if the new setting IP address is occupied.

3.3.24 Rapid IP Discovery

Connect the cable to tester’s LAN port. Press  to enter Rapid IP Discovery app.

Click “Start” to search all IP address of connected equipments in whole network segment.


Click “Stop” to stop work.



3.3.25 PoE power / DC12V 2A and DC 5V 2A USB power output


When the tester is turned on, the 12VDC and 5VDC power output functions are automatically turned on.

If the tester is turned off, the 5VDC USB can still be used to power an external USB device.

To use the PoE Power Output function, click on the icon  and change the switch “ON” or “OFF”.

The IP camera needs to be connected to the LAN port before you turn PoE Power on. If the IP camera Supports PoE, the PoE power is delivered via pins 1, 2, 3, and 6 ; 4,5,7and 8 on the LAN port. The IP tester will

display “48V ON” at the top of the screen when the POE power is still on.






#### Note:

1. Don't input power into the "DC12V/2A OUTPUT" port.
2. Don't output DC12V/2A power to the DC12V/IN port of the Integrated Mount Tester to avoid damage.
3. The Integrated Mount Tester power output is close to 2A, if the IP camera's power is over 2V, the tester will auto enter protection mode. Disconnect all the connections of the tester and then connect the tester with power adaptor to resume the tester.
4. Before turning on the PoE power output, please make sure the IP camera supports PoE power. Otherwise it may damage the IP camera.
5. Make sure you plug in your IP camera to the LAN port prior to turning on PoE power.
6. Make sure the tester is full charged or more than 80% charged, otherwise the tester will show "low power", "not able to supply power" PoE voltage test

Click icon  to enter PoE voltage measurement.



Connect a network cable from a PoE switch to the tester's PSE IN port. Connect an IP camera or other PoE using node to the tester's LAN port, the PoE voltage and the cable's pin connection status show on the screen.



**Note:** This test is for measuring the voltage being drawn by the PoE node and the tester must be between the PoE switch and the PoE node for this test to work.

**Note:** The PoE switch must be connected to the PSE IN port. The powered device such as IP

camera or other PoE node must be connected to the LAN port.




**Note:** Do not connect PoE power supply equipment (such as a PoE switch) to the tester's UTP/SCAN port; otherwise it will damage the tester.

**PSE transmission**

When PoE / PSE voltage testing, PoE/PSE connect to the tester's PSE "IN" port , the camera connect to tester's Lan port , tester not only can transmit voltage to supply power for camera ,but also transmit data at the same time. as well as the computer connect to the PoE/PSE, it can log in connected tester's PoE camera.

**3.3.26 12V power input test**

Connect 12V power adaptor to tester's charging port, then click icon “PoE” to enter voltage measurement app ,screen show the current adaptor input voltage and power. Note: the current 12V input measured power is the battery charging power and the device working power,the measured power will change depending on the different of battery power and backlight brightness.



**Warning:** Not allow connect device with input power over 17V to tester “12V IN”port,otherwiseit will damage the machine.

3.3.27 Digital Multi-meter

Click icon  to enter.



1) SYMBOLS:

AUTO: Intelligent gear, which can automatically switch DC voltage, AC voltage, resistance and on-off measurement.

- U: DC Voltage Measuring

Ω: Resistance Measuring

U~ AC Voltage Measuring

))) Continuity Testing

$\sim V$ : Frequency testing
- A: DC Current Measuring

$\nabla$ : Diode Testing

A~ AC Current Measuring

$\equiv$ : Capacitance Measuring

$\nabla \equiv$ : Neutral and live wire testin


AC/DC	Voltage and current measurement state display.
Auto- range	The Multimeter auto adjust the range by input signal or tested components.
Data hold	Hold data
Relative measurement	Display the relative measurement value. Press the key to change display state.
10A socket	In 10A current measurement state ,indicate use 10A socket.
Over range	The current measurement value over the range, if in the Auto range state, to switch Auto.



## 2) OPERATING INSTRUCTION

### A. Auto measurement

1. Connect the black test lead to the "COM" jack and the red test lead to the "V/ $\Omega$ " jack.
2. Select "Auto", can measure the DC voltage, AC voltage, Resistance and Continuity Testing



AUTO unconnected



DC/AC Voltage Testing



Resistance Testing



Continuity Testing

### B. DC Voltage Measuring

#### WARNING!

You can't input the voltage which more than DC 660V, it's possible to show higher voltage, but it's may destroy the inner circuit.

Pay attention not to get an electric shock when measuring high voltage.

a. Connect the black test lead to the “COM” jack and the red test lead to the “V/ $\Omega$ ” jack.

b. Select U, enter the DC voltage measurement.

c. the tester default Auto range status ,by click “DC auto range”, press


key can select manual range and restore auto range .

Manual range: 0.000V  $\rightarrow$  6.600V range

00.00V  $\rightarrow$  66.00V range

000.0V  $\rightarrow$  660.0V range

000.0mV  $\rightarrow$  660.0mV range



## B. AC Voltage Measuring

### WARNING!

You can't input the voltage which more than AC 660V, it's possible to show higher voltage, but it's may destroy the inner circuit.

Pay attention not to get an electric shock when measuring high voltage.

a. Connect the black test lead to the “COM” jack and the red test lead to the “V/ $\Omega$ ” jack.

b. select U ~ , enter the AC voltage measurement.

c. the tester default Auto range status, by click “AC auto range”

d. Manual range can be select , press the key “NEAR” to restore Auto range.

e. Manual range: 0.000V  $\rightarrow$  6.600V range

00.00V  $\rightarrow$  66.00V range

000.0V  $\rightarrow$  660.0V range

000.0mV  $\rightarrow$  660.0mV range

## C. DC Current Measuring (only manual range )

### WARNING!


Shut down the power of the tested circuit, and then connect the meter with the circuit for measurement.

a. Connect the black test lead to the “COM” jack and the red test lead to the “mA” jack for a maximum

of 660mA current. For a maximum of 10A, move the red lead to the 10A jack.

b. select **A**, enter the DC current measurement, the screen display "DC current", can select manual range.

- c. Manual range:
- |         |   |                               |
|---------|---|-------------------------------|
| 0.000mA | → | 6.6mA range                   |
| 00.00mA | → | 66.00mA range                 |
| 000.0mA | → | 660.0mA range                 |
| 00.00A  | → | 10.00A range (use 10A socket) |



d. Select the range to enter current measurement.



#### NOTE:


- ◆ When only the figure "OL" is displayed, it indicates over range situation and the higher range has to be selected.
- ◆ When the value scale to be measured is unknown beforehand, set the range selector at the highest position.
- ◆ The maximum current of mA socket is 660mA, over-current will destroy the fuse, and will damage the meter.
- ◆ The maximum current of 10A socket is 10A, over-current will destroy the meter, and will damage the operator.

#### D. AC Current Measuring (Only Manual range)

##### WARNING!

Shut down the power of the tested circuit, and then connect the meter with the circuit for measurement.

a. Connect the black test lead to the "COM" jack and the red test lead to the "mA" jack for a maximum of 660mA current. For a maximum of 10A, move the red lead to the 10A jack.



b. select  $\tilde{A}$ , enter the AC current measurement, manually select the range.

- c. Manual range: 0.000mA → 6.600mA range  
 00.00mA → 66.00mA range  
 000.0mA → 660.0mA range  
 00.00A → 10.00A range(use 10A socket)



Note:

- ◆ When only the figure “OL” is displayed, it indicates over range situation and the higher range has to be selected.
- ◆ When the value scale to be measured is unknown beforehand, set the range selector at the highest position.
- ◆ The maximum current of mA socket is 660mA; over-current will destroy the fuse, and will damage the meter.
- ◆ The maximum current of 10A socket is 10A, over-current will destroy the meter, and will damage the operator.
- ◆ In” AC “ mode, only can input “AC “, if not, will damage the meter.
- ◆

## E. Resistance Measuring


### WARNING!

When measuring in-circuit resistance, be sure the circuit under test has all power removed and that all capacitors have discharged fully.

- a. Connect the black test lead to the “COM “ jack and the red test lead to the “V/ $\Omega$ ” jack.

- b. to select  $\Omega$ , enter the  $\Omega$  measurement

the tester default Auto range status, Press the key manually select range ,Press “NEAR” to restore “Auto range”



Manual range:(Connect the red lead to black leads, will display the measure range)

- 000.0 $\Omega$  → 660 $\Omega$  range  
 0.000 K $\Omega$  → 6.600K $\Omega$  range  
 00.00 K $\Omega$  → 66.00K $\Omega$  range

000.0 K $\Omega$  → 660.0K $\Omega$  range


0.000 M $\Omega$  → 6.600M $\Omega$  range

00.00 M $\Omega$  → 66.00M $\Omega$  range

## F. Continuity Testing

### WARNING!

When testing the circuit continuity, be sure that the power of the circuit has been shut down and all capacitors have been discharged fully.



- Connect the black test lead to the “COM” jack and the red test lead to the “V/ $\Omega$ ” jack.
- to select  $\varnothing$  , enter the continuity test, Connect test leads across two point of the circuit under testing.
- If continuity exists (i.e., resistance less than about 50 $\Omega$ ), built-in buzzer will sound.


## G. Diode Testing

### WARNING!

The capacitance of a capacitor should be tested separately, should not test in the installation of circuit.

- Connect the black test lead to the “COM” jack and the red test lead to the “V/ $\Omega$ ” jack. (the red lead anode “+” ) .

- to select  $\nabla$  , enter the diode testing.



- Connect test red lead across to the anode, the black lead to the cathode of the diode under testing.
- Connect test red lead across to the cathode, the black lead to the anode of the diode under testing.
- Tested diode, forward voltage low 30mv, there is sound indication ,then can finish the testing quickly

without view the screen.


## H. Capacitance Measuring

### WARNING!

To avoid electric shock, be sure the capacitors have been discharged fully before measuring the capacitance of a capacitor.

- Connect the black test lead to the "COM" jack and the red test lead to the " $V/\Omega$ " jack.
- Select " $\text{---}\text{||}\text{---}$ " to enter, enter the capacitance measurement.
- The tester default auto range status, and manual range by press upward and downward key, Auto rang by press the key "NEAR"

Manual range: 0.000nF	→	6.600nF	range
00.00nF	→	66.00nF	range
000.0nF	→	660.0nF	range
0.000uF	→	6.600uF	range
00.00uF	→	66.00uF	range
000.0uF	→	660.0uF	range
0.000mF	→	6.600mF	range
00.00mF	→	66.00mF	range




- Before connect test leads across two sides of the capacitor under measurement, be sure that the capacitor has been discharged fully.



Note:

- The capacitance of a capacitor should be tested separately, should not test in the installation of circuit.
- To avoid electric shock, be sure the capacitors have been discharged fully before measuring the capacitance of a capacitor.
- While testing the capacitance of a capacitor to 660uF, the Max time will be 6.6 seconds, if the capacitor is leaked or damaged, the data can't be read. The tester will be normal after disconnecting the capacitor.



## Frequency Testing

1. Connect the black test lead to the "COM" jack and the red test lead to the "V/ $\Omega$ " jack.
2. Select " $\sqrt{\text{Hz}}$ ", enter frequency testing mode




注意: Warning

The Frequency range must be less than 6M

## Neutral and Live wire detection

1. Connect the red test lead to the "V/ $\Omega$ " jack
2. Select " $\text{N} \perp \text{L}$ ", enter neutral and live wire detection mode
3. Connect the red test lead to socket, the live wire has buzz sounds, the neutral wire no buzz sounds



Warning

Please check that the probes are not damaged before use, During the measurement of the neutral and live wire, don't directly touch the metal part of the probes to avoid danger.

## Test report

Click "Start" will start creating the report and recording the current real-time measurement data. Click "Stop" to complete the data recording and create the test report. In the sleep mode, will stop the data recording

## Manual range and Auto range

When testing, click "Range select" to change the value, click "Auto range" to enter Auto measurement.



### Data hold

Click “Hold data” to enter, the data be hold, the value is green. Press it again to quit.

### Relative value measurement

Click “Relative “to enter, the tester Auto-save the data, the displayed new measurement and relative value is red color. Press it again to quit.

The hold function and the relative value be combined use, the display value is yellow.

### The meter protection

#### ➤ Voltage protection

You can't input the voltage which more than AC 660V, it's possible to show higher voltage, but it's may destroy the inner circuit.

#### ➤ Resistance, Continuity, Diode, PTC component Protection

Wrong input voltage, will Auto enter protection state , It only suitable for short and limit time work.

If input voltage over 600V, will damage the meter.

#### ➤ mA current fuse range: 250V 1A

if the current over the rated range ,fuse will melt to protect the meter ,please use the same model when change the fuse, please opens the battery cover to change.




**Note:** 10A socket without fuse protection, if over the current range.

**Wrong using the 10A socket to measure the voltage, will damage the meter.**



### 3.3.28 Optical power meter


Click icon  to enter, with five wavelength 1625nm, 1550nm, 1490nm, 1310nm, 1300nm, 850nm, linear or nonlinear optical power display, both for optical power testing and fiber link loss relative measurement. It is necessary tool for installation and maintenance optical fiber communication, cable television and CCTV security system.



**Note:** Please keep the fiber connector and the dust cap be clean, and clean the detector with the special alcohol.


#### Data hold

While testing, click “Hold” to data hold, the data will not change. It’s convenient to read. Press again to quit.




#### Relative power value (optical link loss) measurement

While testing, set the wavelength for measurement. Click “relative”(difference) to test, the tester Auto save current fiber power value as the base reference value. Input another optical fiber to be measured, the displayed new measurement and relative value is red color. Press it again to quit.



Data hold and Relative measuring use together, the data is yellow while the function is effect.



### 3.3.29 Visual Fault Locator


Open Dust Cap, connect fiber to tester's VLS interface.



Click icon




to enter.



VFL four statuses can select——”Steady mode”, “Evasive 1Hz”, “Evasive 2Hz”and”Time off”. Click button “Steady mode” to enter steady status, click button “Evasive 1Hz” and “Evasive 2Hz, to enter pulse mode, click button “Time off”, VFL is turned off. Timed turn off can select (5 mins, 10 mins, 30 mins, 60 mins and 120 mins).






Click” Steady mode”, red laser source emits steady, click again to quit.



Click icons “Evasive 1Hz”or”Evasive 2Hz”to enter pulse mode, the red laser source is emitted by a certain frequency, press it again to quit.


3.3.30 Audio Record



Connect an audio device to the Integrated Mount Tester’s audio input port. Click the  icon to enter the Audio Recorder app. Click the red button to stop, and the unit will prompt you to save the recording.




Click “Audio in record”, will switch to "MIC record", can record and save the audio from microphone.

3.3.31 Data monitor

Please click icon  to enter.




Click “Setting” to choose the baud rate of RS485; it must be the same as the DVR or the Control. keyboard .The DVR or Control keyboard send the code to the tester, if it can be read, the protocol will shown on the upper right, like Pelco D, if not, like P:---


**While the tester receives the code, press the  key to empty.**

Though the RS485 port, display the PTZ control code of the multifunctional keyboard or the DVR. Controller can check the status of the RS485 transmission through the code on the display. (The RS485 communication rate must be the same.)

**Application:** Check the RS485 communication states of the video optical transmitter whether normal. Engineer can analyze the protocol and check the data through the displayed code.

### 3.3.32 Audio player

Click the icon  to enter . The audio player only supports MP3 format Audio files.





### 3.3.33 Media Player


Click the icon



to enter.




The Media player can browse video and image files. It supports the video formats of MP4, H.264, MPEG4, and MKV. The Integrated Mount Tester recorded files can play directly via the Media player. The Media player will automatically display the video files from the tester Click on the desired file to play. Click RETURN to exit.




To rename or delete an existing file, press the file name for a few seconds until the screen below appears. You can then rename or delete the file by pressing the desired option.

### 3.3.34 Update

Copy the downloaded update file to SD card "update" directory, if no directory, please create one.


Click the  icon to open the Update menu. Select "Local Update" to update via the SD card or select "Online Update" to check for updates on the internet. If there are applications that need updating, the applications will be displayed on the screen.




If there are update programs, applications will be listed in the interface, click related applications, update to the latest version.


Update online: Before using online update, need enter settings-user management to register first.

**3.3.35 LED Flashlight**

It is convenient for the installation or maintenance in the evening or in the dark. Click icon  to enter.



While in the flashlight app, click the red button to turn on the LED lamp. Press it again to turn it off. If

you don't press the red button  to shut off the lamp and press the button to exit the app, the lamp will stay on. Click the Time Setting button to set a timer that will shut off the lamp.

3.3.36 Browser

Click icon  to enter.

Type in the camera's IP address and press “Go” to access the IP camera's interface.


**NOTE: You will not be able to view live video in the web browser. For viewing video, use the**



The IP camera and the tester be on the same network segment for the browser to interface with the camera. If they are not in the same segment, click the button or press “RETRUN” to exit. Open the “Settings” app from the main menu to change the IP tester's network settings to match those of the IP camera.

3.3.37 DroNotes

DroNotes can be used to record the important testing results, click the key “Save” to save the contents. Notepad can auto record the storage date and time.



3.3.38 System Setting



Click icon  to enter.


**Language:** Select your desired language: English, Chinese, Korean, Russian, Italian , Polish ,Spanish, French or Japanese.

**Typewriting:** You can select typewriting or install other typewriting:



**Date/Time:** Set the Date/time of the Tester.

**IP setting:** Manually set the IP address, Sub-net Mask, Default Gateway and DNS address or select “Dynamic allocation” to use DHCP. To test multiple network segments, click “Advanced” and then click “Add” to enter another IP address for the Tester.




After setting an advanced IP address (refer to the photos above), the unit can test two network segments

(192.168.5.0) and (192.168.1.0).


**Volume:** Set volume level.

**SD Card:** Displays SD Card Capacity. You can also format the SD card or unmount it before removing it.

**FTP server:** Once the tester connects to a network, a computer can be used to read the SD card files via FTP.



Start the FTP server and then input the tester’s FTP address in the PC’s address bar. This will enable the PC to read ,copy and edit the files from the SD card without the use of SD card reader.



**Version information:** Shows applications version information, if press any apps icon several seconds to uninstall.

**Screen display rotation::**Click on “Screen Rotation” to flip the tester’s display 180 degrees. This function is very convenient for the user to connect the LAN cable on the bottom of the unit without having to flip the unit itself.

**PTZ address scan:** You can toggle the PTZ Address scan off or on before entering the “PTZ controller” app. This needs to be turned on in order to use the PTZ Scan feature of the PTZ app.

**Online Registration:** Online update need register first, after the tester connect to network, then fill registration information to register.

**User Feedback:** if you have any comments or suggestions for the tester, please connect it to network and write your feedback.

**Lock Screen:** the meter default is not locked. You can choose password Lock screen, pattern Lock screen or “NO” .

**Password Lock Screen:** Set password, you can input digitals, letters or characters as password, input it again to confirm .when the meter is in standby mode or turn it on, you can input your password to enter.


**Pattern Lock Screen:** Drawing a pattern to lock. While the meter is in standby mode or turn it on, you can input your pattern to enter.

Modify Lock screen password, you need input lock password again. Select password Lock screen or pattern Lock screen to reset lock screen password. After reset pattern lock screen, you need to draw a new lock pattern.

**Restore the factory settings:** If the tester to restore factory settings, all your personal files and apps will be removed.


### 3.3.39 File explorer

Click “File “on the top bar tool, can enter internal. Click on the upper right corner Icon”... “.will pop-up menu, you can select other operation or exit.




**Browse**

It includes Music, Videos, Pictures, Documents, zip file etc. It is convenient to view and manager.



### FTP server

You can choose internal or external SD card. Other operation details, please refer to FTP settings.



### 3.4 Audio test

You can test the audio input from audio pickup devices by connecting the audio pickup device to the tester with the supplied audio cable.



### 3.5 HDMI output

The built in HDMI output port can output live video from an analog or IP camera, recorded files, media files and images to HDTV monitors. Connect an HDMI cable from the tester to an HDTV monitor at any time. It supports up to 1080P resolution.

### 3.6 PoE power output

The tester supports PoE (Power over Ethernet) output to an IP camera via the LAN port. Data transmission and POE 48V use the network cable's 1, 2, 3, and 6 pins; 4, 5, 7 and 8 pins to deliver power. If the IP camera supports PoE, you can directly connect to the camera without the use of an external power supply.



#### Notice

- Please make sure the cable connected to the tester's Lan port is straight-line cable and has no short circuit, otherwise will damage the tester.
- Before using PoE power output, please check the IP camera whether supports POE powered. Otherwise it will damage the IP camera.



- d. The instrument's PoE maximum power output is 24W. If Ultra- high-power load happens, the tester will enter protection mode .

### 3.7 DC12V 2A power output

When the IPC tester is turned on, the DC 12V power output ON by default. The smaller end of the supplied converter cable connects to the tester's DC12V/2A OUTPUT and the other end connects to the camera's power input.



## Application

Power output function is mainly used in the camera field demonstration and testing, meanwhile, for some cameras installation sites, If there is no power outlet for the adapter to power the camera, the tester can offer temporary power for it. But we do not suggest tester supply power for a long time.



### Notice:

- a. Don't input any power into the "DC12/2A OUTPUT" port of the tester.
- b. Man-made damage is not within our company's warranty.
- c. The tester's power output capacity is 2A. If the IP camera uses more than 2A, the tester will automatically enter a protection mode.
- d. Disconnect all cables from the tester and reboot it to resume using the tester.

The tester's power output is close to 2A, if the IP camera's power is over 2V, the tester will auto enter protection mode. Disconnect all the connections of the tester and then connect the tester with power adaptor to resume the tester.

- e. Make sure the tester has a sufficient charge, otherwise tester can't provide enough output power.

## 3.8 USB 5V 2A power output

When the tester is turned on, the DC 12V and DC 5V power output functions are automatically turned on. If the tester is turned off, the DC 5V USB can still be used to power an external USB device.

**NOTE: The USB port is for power only and not data.**



The user manual in the accessory bag is for reference only, please refer to the electronic version in the disk for updated information.

The user manual in the accessory bag is for reference only, please refer to the electronic version in the disk for updated information.